## CIRCUIT INSPECTION

DI8RZ-01

## **Power Source Circuit**

## **CIRCUIT DESCRIPTION**

This circuit provides power to operate the rain sensor.


The auto wiper system is operated the wiper switch being in the auto position.

The rain sensor is connected to each ECU at the multiplex communication circuit.

When it detects raindrops that are stuck to the detection area of the windshield glass, it sends the wiper control signal according to the amount of raindrops to the Passenger Side J/B ECU.

It also sends signals to the radar cruise control system, the mirror defogger system and others.

# **WIRING DIAGRAM**



## INSPECTION PROCEDURE

1 Check P

Check[P-IG[fuse.

#### **CHECK:**

Check@continuity@fP-IGfuse.

OK:

Continuity

NG□

Replace[the[failure]fuse.

OK

**2**[]

Check[voltage[between[terminal]\$IG[and[ES[of[rain[sensor.

### **PREPARATION:**

(a) Turn ignition switch ON.

(b) Disconnect the rain sensor connector.

### **CHECK:**

Measure[voltage[between[]erminals[\$IG[and[ES[bf[]ain[]sensor.

OK:

Voltage: 10 - 14V

ок□

Proceed\_to\_next\_circuit\_inspection\_shown\_on problem\_symptoms\_table\_(See\_page\_DI-985).

NG

3□

Check[wireharness[and[connector[between[rain[sensor[and[body[ground[Seepage[N-35]].

NG

Repair or replace wireharness or connector.

OK

Check and repair wireharness and connector between ECU and battery.