PRESSING[POWER[\$WITCH[DOES[NOT]TURN[ON[\$YSTEM

INSPECTION PROCEDURE

1 CHECK CABIN

(a) Check that conditions in the cabin are likely to cause condensation.

HINT:

This problem occurs when the cabin is humid and the temperature changes papidly. This may produce condensation, resulting in a short circuit.

OK: Condensation is not likely.

NG□

DRY[CABIN[AND]RECHECK[CONDITIONS

OK

PROCEED[TO[NEXT[CIRCUIT[]NSPECTION[\$HOWN[]N[PROBLEM[\$YMPTOMS[TABLE (SEE[PAGE[05-1660)]