05H0S-01


ROAD TEST


1. PROBLEM SYMPTOM CONFIRMATION

HINT:

The dynamic radar cruise control system has 2 cruise control modes: the constant speed control mode and vehicle—to—vehicle distance control mode.

- The vehicle—to—vehicle distance control mode is always selected when starting up the dynamic radar cruise control system.
- Operation of a constant speed control mode is the same as that for a conventional type cruise control system.
- (a) Inspect the SET function.
 - (1) Turn the main switch ON.
 - (2) Drive vehicle at 40 km/h (25 mph) or higher.
 - (3) Set the main switch to SET/COAST.
 - (4) After releasing the switch, check that the vehicle cruises at the set speed.






- (b) Inspect the ACCEL function.
 - (1) Turn the main switch ON.
 - (2) Drive vehicle at 40 km/h (25 mph) or higher.
 - (3) Set the main switch to SET/COAST.
 - (4) Check that vehicle speed increases while the main switch is set to RES/ACC, and that the vehicle cruises at the newly set speed when the switch is released.
 - (5) Momentarily (approximatery 0.6 seconds) set the main switch to RES/ACC and then immediately release it. Check that vehicle speed increases* (tapup function).

HINT:

- *: Constant speed control mode: increases by 1.6 km/h (1.0 mph); vehicle—to—vehicle speed control mode: increases by 5 km/h (for meters indicated by km/h) or 5 mph (for meters indicated by mph).
- (c) Inspect the COAST function.
 - (1) Turn the main switch ON.
 - (2) Drive vehicle at 40 km/h (25 mph) or higher.
 - (3) Set the main switch to SET/COAST.
 - (4) Check that vehicle speed decreases while the main switch is set to SET/COAST, and that the vehicle cruises at the newly set speed when the switch is released.




(5) Momentarily (approximatery 0.6 seconds) set the main switch to SET/COAST, and then immediately release it. Check that vehicle speed decreases* (tap-down function).

HINT:

(1)

139281

- *: Constant speed control mode: decreases by 1.6 km/h (1.0 mph); vehicle—to—vehicle speed control mode: decreases by 5 km/h (for meters indicated by km/h) or 5 mph (for meters indicated by mph).
- (d) Inspect the CANCEL function.
 - (1) Turn the main switch ON.
 - (2) Drive vehicle at 40 km/h (25 mph) or higher.
 - (3) Set the main switch to SET/COAST.
 - (4) When performing one of the following, check that the cruise control system is cancelled and that the normal driving mode is reset.
 - Depressing the brake pedal
 - Moving the shift lever to any position except
 D (6th, 5th, and 4th gears)
 - Turning the main switch OFF
 - Setting the cruise control main switch to CAN-CEL



SET/COAST

- (e) Inspect the RES (RESUME) function.
 - (1) Turn the main switch ON.
 - (2) Drive vehicle at 40 km/h (25 mph) or higher.
 - (3) Set the main switch to SET/COAST.
 - (4) When performing one of the following, check that the cruise control system is cancelled and that the normal driving mode is reset.
 - Depressing the brake pedal
 - Moving the shift lever to any position except
 D (6th, 5th, and 4th gears)
 - Setting the cruise control main switch to CAN-CEL
 - (5) After setting the main switch to RES/ACC at a driving speed of more than 40 km/h (25 mph), check that the vehicle restores the speed prior to the cancellation.

HINT:

RESUME function in the vehicle-to-vehicle distance control mode only:

The stored vehicle speed is retained even if vehicle speed decreases below 40 km/h (25 mph) once. The previously stored vehicle speed can be resumed by setting the cruise control main switch to RES/ACC when vehicle speed returns to approximately 40 km/h (25 mph) or more.